

CE5BC Genesis Tank - User Guide



To fill the Tank, remove Coil (1) from Tank Base (2) by turning anti-clockwise. Turn Tank over and fill from the Tank Base (2). DO NOT overfill the tank or allow liquid to enter the Internal Plastic Air Tube (3). Only fill tank to maximum per the scale on the side of the Tank.

When completed, replace coil in bottom of tank by turning clockwise.

Ensure the Coil (1) is fully tightened.